

# HUUM Heater / Element Chart

Stove	Required Element(s)	Element Quantity
<b>DROP</b>		
4.5 kW	DROP-EL15	3
6 kW	DROP-EL20	3
7.5 kW	DROP-EL15	5
9 kW*	DROP-EL15 & DROP-EL20	3 & 2
<b>HIVE Mini</b>		
6 kW	HIVE-EL20	3
9 kW	HIVE-EL30	3
10.5 kW	HIVE-EL35	3
<b>HIVE</b>		
12 kW	HIVE-EL20	3
15 kW*	HIVE-EL20 & HIVE-EL30	3 & 3
18 kW	HIVE-EL30	6
<b>STEEL Mini</b>		
3.5 kW	SLIM-EL35	1
<b>STEEL</b>		
6 kW	SLIM-EL20	3
9 kW*	SLIM-EL20 & SLIM-EL35	1 & 2
10.5 kW	SLIM-EL35	3
<b>CLIFF Mini</b>		
3.5 kW	SLIM-EL35	1
<b>CLIFF</b>		
6 kW	SLIM-EL20	3
9 kW*	SLIM-EL20 & SLIM-EL35	1 & 2
10.5 kW	SLIM-EL35	3

\* Indicates a Stove that uses two different elements together.  
Quantity required in order of appearance.